

Institute for Soldier Nanotechnologies

John D. Joannopoulos

Director, Institute for Soldier Nanotechnologies

Francis Wright Davis Professor of Physics

Massachusetts Institute of Technology

Selected Research Highlights & Potential Impact for Army Applications

Army Science Conference

December 1-4, 2008




**Massachusetts
Institute of
Technology**





Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE DEC 2008		2. REPORT TYPE N/A		3. DATES COVERED -	
4. TITLE AND SUBTITLE Selected Research Highlights & Potential Impact for Army Applications				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Institute for Soldier Nanotechnologies				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited					
13. SUPPLEMENTARY NOTES See also ADM002187. Proceedings of the Army Science Conference (26th) Held in Orlando, Florida on 1-4 December 2008, The original document contains color images.					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UU	18. NUMBER OF PAGES 27	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			



Mission & Goals



To dramatically improve the survivability of the Soldier by working and extending the frontiers of **Nanotechnology** through fundamental research ... and transitioning with our Army & Industry Partners





What is Nanotechnology?



Properties of materials (e.g. electronic, photonic, mechanical, magnetic) become **size dependent** below a critical length scale of ~ **500 nanometers**.

(The diameter of a human hair is about 80,000 nanometers)

Opportunities:

- **New** materials, **new** phenomena, **new** properties
unattainable in nature



A Three-Member Team




ISN Dedicated Facility

State of the art
instrumentation



- 47 Faculty (10 Departments)
- 80 Grad students
- 30 Post-docs
- 2 Uniformed Army Scientists
- 3 Civilian Army Scientists
- 2 Industry Scientists
- 1 USN/MC TTS
- 1 Uniformed Army Liaison

Industry Consortium



Army Sci & Tech Labs





Potential Impact for Army App's





- 1 – Low-cost, room-temperature night-vision and communications in the infrared (IR) for **increased Soldier situational awareness**
- 2 – Autonomous and self-administered medical care for **faster, more extensive, far-forward medical treatments**
- 3 – Lightweight, flexible & breathable structural materials for **comfortable blast & ballistic protection**
- 4 – Flexible, lightweight nano-coatings for **multiple survivability capabilities**
e.g., against moisture, bacteria, spores, hazmats, fire, EMI ...
- 5 – Multi-functional *full-body* battlesuit to **enhance the Soldier's senses of light, heat, and sound**
- 6 – Ultra-sensitive explosives sensors for **accurate hand-held, robot-integrated, and stand-off IED detection**


Supporting FOC's: Battlespace Awareness, Battle Command, Human Dimension, Maneuver Support, Maneuver Sustainment, Protection

★ **Nanoparticle systems as low-cost room-T devices for IR sensing & comms:**
Enhance situational awareness in the battlespace

**Band-Gap Engineered Nanocrystals (aka QDs)
 & Low-Cost Polymer Processing**



PbSe NanoXtals 3 nm to 10 nm




- Develop low-cost QD-based optoelectronic devices in the visible & IR

★ Nanoparticle systems as low-cost room-T devices for IR sensing & comms:
Enhance situational awareness in the battlespace

Hydroxyl nightglow dominates $\sim 1000 - 2300 \text{ nm}$

Si-CCD NIR $< 1000 \text{ nm}$



E. Sargent

InGaAs SWIR $1000-1700 \text{ nm}$
 (very expensive)



E. Sargent

- Develop low-cost QD-based optoelectronic devices in the visible & IR



Development of IR imager based on solution synthesized colloidal nanocrystal quantum dots



M. Bawendi
V. Bulovic
M. Kastner
S. Geyer

**Nanocrystal
Synthesis**

**Photodetector
Fabrication**

**Electro-Optic
Response**

ARL SEDD
P. S. Wijewarnasuriya
V. J. Nathan



NVSED
R. Littleton

Raytheon

F. B. Jaworski







**Focal Plane
Array Design**

**Read Out
Electronics**

**Figures of Merit
Determination**

**Test Device & Focal
Plane Arrays**

**Nanocrystal Based
IR Imager**





Novel QD(nanoparticle)/Dye Constructs as Environmental Reporters for Medical Diagnostics & Toxin Sensing







M. Bawendi
D. Nocera

Ratiometric, quantitative FRET between QD & sensing dye molecules: measure pH, blood O₂ & glucose, or detect hazardous substances



ERDC/CERL
A. Kumar

Reversible sensing modalities






Development of autonomous & self-injected drug delivery with wearable & implantable MEMS-based devices in the battle space:




M. Cima
N. Elman

Develop Rapid Reconstitution Packages (RRP's) to improve drug instability & deployment logistics: e.g. use for hemorrhagic shock, TBI, chem/bio agents





Auto-injection
(RRP) for trauma




Wearable (RRP)
for auto/remote
actuation



Implantable
SubQ device



Atropine reservoir



Mixing Solution

Rapid Reconstitution of Atropine









Development of ceramic nanoparticle-reinforced novel architectures for potential flexible, lighter-weight & stronger armor





**Picatinny
Arsenal
D. Kapoor**


**N. Thomas
M. Boyce
S. Kooi**



Bio-inspired Layered Composites



★ Enable the first CNT/graphene-linked flexible “Chain Maille” structures using precision placement of anisotropic nanostructures



π - π Stacking
of Alternating
Chain Maille Layers





CERL/ITL
C. Marsh
C.R. Welch

Micro-hydrodynamic
Placement Allows Massively
Parallel Alignment/Placement


Atomistic Modeling
&
Mechanical Testing



WMRD
A.J. Hsieh





Pattern Chain Maille
Networks of Carbon
Nano-materials



★ **Gentle** Chemical Vapor Deposition (CVD) methods for enabling **multi-functional** polymer coatings of fibrous & hard surfaces:


*CVD processing for both **insulating** & **conducting** polymers!*




Conformal coverage!

★ **Gentle** Chemical Vapor Deposition (CVD) methods for enabling **multi-functional** polymer coatings of fibrous & hard surfaces:

CVD processing for both *insulating* & *conducting* polymers!



oCVD



with K. Senecal




: develop resistivity-based sensor for pathogens

- Develop for a broad-range of sensing and protective coatings (toxic agents, water-repellency, fire-retardency, EMI-shielding, etc ..) for the battle-suit and face shields

★ Flexible dielectric Bragg reflectors (DBRs) for laser eye protection




K. Gleason



Room-T deposition
of flexible polymer
layers sandwiching
thin inorganic
layers



John Lock
(ISN Alum)
Norm Rice
Pete Schuler




WMRD

A. Rawlett



NSRDEC


B. Kimball





Towards novel optoelectronic **fiber-devices**:

Full-body sensing – new paradigm fibers & fabrics that can see, feel, hear...




Full Body Combat ID;


Laser-to-Uniform
Non-RF

Communications;

Improved MILES



Full Body
Thermal Sensing
Remote Combat
Triage







Design, fabricate, and implement an optoelectronic **fiber-device** covering for combat ID and line-of-sight IR communication



Y. Fink
J. Joannopoulos
MAJ R. Blair



NSRDEC
R. Elder
R. Masadi
K. Shukla
A. Taylor




Optoelectronic Fiber-Device



ID & Comms Multifunctional Helmet





- Transition to civilian medical community: Fibers for novel CO₂ laser endoscopic surgery
 - Fibers for acoustic detection, photovoltaic & thermoelectric (cooling) applications
 - Fibers for improved FIDO sensing element



Development of *Amplifying Fluorescent Polymers* for high-sensitivity detection of chemicals:

Ultra-sensitive IED detection in theater and ... US ports of entry

Championed by HQDA



**Transportation
Security
Administration**

“TSA ... announced operational pilot testing ... of a technology capable of screening sealed bottled liquids... Fido PaxPoint .”

- Develop AFP's for broad range of explosives



★ Versatile lightweight small form-factor ISN-fiber explosives sensors with *high-sensitivity, multi-analyte* and “*stand-off*” detection capabilities





Y. Fink
J. Joannopoulos
O. Shapira




L. Takiff
A. Rose



PBG fiber provides
15-fold signal
enhancement



SIMM fiber upon
exposure to liquid
explosive vapor




SIMM fibers for explosives detection: upon exposure to solid or liquid explosive vapors, the fiber converts light emission at the core to an electrical signal. Each fiber in bundle can be designed sensitive to a different type of explosive


Resonant cavities in **photonic crystal** nanostructures can be tuned to almost “any” desired frequency, “any” evanescent tail extent, and can exhibit **magnetic** resonant behavior even in a purely dielectric material

As a first step & simple proof of principle: explore energy transfer through evanescent-tails of **simple** self-resonant magnetic coils:


*Exploit “strong coupling” regime: coupling strength » loss rate for **efficient** energy transfer*



Magnetic Resonance



SCIENCE, 317, 83 (2007)



Nanotechnology-Enabled Enhanced Survivability for the Soldier by Exploiting:

- ***Synergistic MIT, Army, Industry Partnership***
- ***Innovative Cutting-edge 6.1 Research Portfolio
to Help Identify “Revolutionary” Opportunities***





Develop flexible nanoparticle metal-alloy fibers that combine high strength with toughness to resist impact and blast:


*Exploit unique deformation mechanisms at the **nano-scale** that can operate at high strength levels and dissipate significant energy without fracture*




C. Schuh
N. Marzari
R. Radovitzky

BUT... nanocrystalline metals are thermodynamically unstable due to high volume fraction of grain boundaries


D. Kapoor



Strength increased with strain-rate
Strength increased with pressure



Demonstration of stable Ni nanoparticles in a Ni-W alloy






★ Development of resistivity-based sensors for pathogens



K. Gleason




NSRDEC
K. Senecal



Poly(pyrrole-co-thiophene-3-acetic acid) functionalized conducting polymer film obtained by oCVD

1 cm

Excellent uniformity !



Optical micrograph of cond. polymer coated fiber mat



Novel QD(nanoparticle)/Dye Constructs as Environmental Reporters for Medical Diagnostics & Toxin Sensing





M. Bawendi
D. Nocera

Ratiometric, quantitative FRET between QD & sensing dye molecules: measure pH, blood O₂ & glucose, or detect hazardous substances




ERDC/CERL
A. Kumar

Reversible sensing modalities



CdSe QD core linked to pH sensitive squaraine dye



In vivo MPLSM of sensors (dye & QD emission) in murine tumor

